



Texas T Parts

711 Ashford Hills Drive
Bryan, Texas 77801

(979) 260-5433 1-800-337-6977
Fax (979) 260-1214
www.TexasTParts.com

Note our
New Address
Everything else
remains the same.



THERMOSTAT INSTALLATION

160° - Cars without water pumps

180° - Cars with water pumps

Remove the **water outlet casting from the head**. Do not try to install the thermostat in the side of the block. It won't fit there. Install the thermostat and new gasket using a thin layer of silicone. Be sure to observe proper flow direction as indicated on the body of the thermostat. The spring goes toward the engine.

If you like our product, tell your friends. If you have a question or a problem, let us know.

Thanks, and Smooth Running,

Texas T Parts